



9201 S. FREEWAY  
FORT WORTH, TX 76140

(817) 293-3018  
(800) 433-2212  
(817) 293-7570 FAX  
(972) 445-5070 METRO

### Dock Mount chain brackets Installation

1. Position yardramp
2. Measure 5" from yardramp lip adjacent to dock face.
3. Measure 24" from dock edge down adjacent to dock face.
4. Mark this location with upper right corner of chain bracket.
5. Mark holes.
6. Drill holes with appropriate concrete anchor bit for anchor bolts being used.
7. Drive in anchor bolts.
8. Position chain bracket over bolts.
9. Tighten anchor bolts securing Dock mounted chain bracket.
10. Pull safety chains from yardramp through dock bracket.
11. Secure chain hook to prevent yardramp from moving.

Chain Bracket Hole Size:  $9/16$ "

Drill Bit Needed:  $1/2$ "

Hardware Needed:  $1/2$ " x 4" Wedge Anchors